


# COBBLE MOUNTAIN DOUBLE CHAIR

## HANGING INSTRUCTIONS

**Please read and follow these hanging instructions. Do not exceed the maximum load limit of 420 lb. Do not let small children play in the chair unattended. Thank you!**

**LOCATION:** You will need to satisfy two considerations: First, a sturdy anchor point overhead about 4-ft. wide, (for the two screw hooks). Nothing less than 2" x 6" framing lumber should be used. Second, you will need space below for the chair to occupy. Roughly the same size that a love-seat or similar piece of furniture would require: An area of approximately 5-feet by 6-feet.

**INSTALLATION OF THE HOOKS:** Using a 5/16" bit, drill two pilot holes into the center of the framing members. Drill straight-up (plumb), about 2" deep. Install the hooks; be sure to bury all the threads.



**HANG AND ADJUST THE CHAIR:** Hang the chair from the hooks and slide the adjusting blocks down the support ropes until the chair is level, the correct height from the floor, and reclined to suit your needs. Toss the cushions in and have a seat. Make further adjustments as necessary for height and angle of recline.

**CARE & MAINTENANCE:** Spot clean the pillows. Clean the ropes using warm, soapy water and a soft bristled scrub brush. Rinse thoroughly and allow to dry completely, preferably in direct sunlight. To spruce up the wood frame, carefully apply furniture oil using a soft, clean cloth. **DO NOT** store your chair where mice or bugs may be present.

**COBBLE MOUNTAIN, INC.**

PO Box 237 – 1051 Village Rd.

East Corinth, VT 05040

800-322-5232 or 802-439-5232

Email: [info@cobblemountain.com](mailto:info@cobblemountain.com) Fax: 802-439-5234

# COBBLE MOUNTAIN DOUBLE FOOTHOLD

## HANGING INSTRUCTIONS

If the Cobble Mountain Double Foothold was included with your Cobble Mountain Double Chair, follow these simple hanging instructions.

**WARNING: DO NOT ATTEMPT TO USE THE FOOTHOLD AS A SEAT. DO NOT ALLOW SMALL CHILDREN TO USE THE CHAIR UNATTENDED.**


Step 1. Adjust your Cobble Mountain Double Chair to the proper height and angle of recline.

Step 2. Hang the Double Foothold from the same hooks that the Double Chair is suspended from.

Step 3. Using the blocks, adjust the Foothold such that it will slide under the chair and the frame of the foothold is parallel to the floor.

To use the foothold, sit in the chair. Reach outside the frame and between front and back suspension ropes. Lift in the direction "A" and push in direction "B" (as illustrated) while lifting your feet. Hook your heels on the foothold; push out until foothold is supporting your feet and lower legs.

To return the foothold to the stowed position simply lift your feet, push down on the open end of the frame and let it swing back under the chair seat.



The Foothold stores neatly under the chair when not in use.